

Charter Township of Brownstown



Department of Public Works
21313 Telegraph Road
Brownstown, MI 48183-1399
734-675-4211 / FAX 734-675-2921
Email: ccinspector@brownstown-mi.org

RESIDENTIAL PROCEDURE TO DISCONNECT IRRIGATION SYSTEM

THE FOLLOWING IS THE ONLY ACCEPTABLE METHOD TO DISCONNECT YOUR IRRIGATION SYSTEM.

1. TURN OFF THE WATER TO YOUR LAWN IRRIGATION SYSTEM.
2. CUT THE IRRIGATION SYSTEM WATER SUPPLY LINE-AFTER THE WATER SUPPLY VALVE- IN YOUR HOUSE.
3. OUTSIDE-CUT THE WATER LINE 2" ABOVE THE GROUND.
4. REMOVE THE BACKFLOW PREVENTER, THE VALVES ATTACHED TO IT, AND THE PIPE ATTACHED TO IT.
5. SOLDER CAP THE PIPE END IN YOUR HOUSE, AND THE PIPE END ENTERING THE GROUND.
6. FILL THE HOLE IN YOUR WALL WITH AN APPROPRIATE MATERIAL OR PRODUCT OF YOUR CHOICE.

CALL 734-675-4211 TO ARRANGE AN INSPECTION OF THE DISCONNECTION, SO THAT OUR RECORDS CAN BE PROPERLY UPDATED.